



GlasBac®/GlasBacRE TacTiles® Connectors Technical Data Sheet

CHEMICAL COMPOSITION

Compounded acrylic adhesive, applied to PET polyester backing with PET polyester release liner.

APPEARANCE

Clear 3" x 3" polyester squares with colored print, supplied on white polyester release liner. Available in rolls or sheets.

PRODUCT SPECIFICATIONS

Solids (%) Greater than 99 %

Dimensions 3" x 3"

PRODUCT DESCRIPTION/APPLICATIONS

GlasBac/ GlasBac RE TacTiles connectors replace adhesives when used to install InterfaceFLOR modular carpet with GlasBac® and GlasBac RE backings, only. TacTiles connectors have an exceptionally low odor and "zero" calculated VOC's, which make them ideal for use in schools, healthcare facilities, public and private buildings and any place where odor is a concern.

TacTiles connectors use a small quantity of a pressure sensitive adhesive, applied on one side of a polyester film, to connect InterfaceFLOR carpet modules together.

TacTiles connectors facilitate installation of InterfaceFLOR modular carpet tile products in a flooring system that is "stable, firm, and slip-resistant and does not pose a tripping hazard." See United States Access Board – Americans With Disabilities Act Accessibility Guidelines – Bulletin #4: "Ground and Floor Surfaces"

Surface preparation requirements for installations with TacTiles connectors are the same as those for installations where adhesives would be used.

TacTiles connectors are not to be used for installing InterfaceFLOR modular carpet onto stairs, over existing carpet surfaces, or on sloped surfaces such as ramps and inclines.

The flammability performance of InterfaceFLOR modular carpet remains the same when TacTiles connectors are used in place of adhesives.

The adhesive used on TacTiles connectors for GlasBac/ GlasBacRE resists water and alkaline solutions, and resists plasticizer migration.

STORAGE CONDITIONS

TacTiles connectors are generally resistant to both moisture and temperature. TacTiles connectors that become wet should be allowed to air-dry before being used.

PRODUCT INSTALLATION

Please refer to the GlasBac/ GlasBac RE TacTiles Installation Instructions for full details. Installation Instructions are available at <http://www.interfaceflor.com/installation>.